



YOUR EYEWITNESS ON THE ROAD™



KPT-942 User Manual

IN-CAR DASH CAM

WITH REAR VIEW CAMERA | GPS | ADAS



full HD 1080p
rear camera



quad HD 1440p
dash cam



gps
logger



g-sensor



lane
departure
warning



forward collision
warning

Caution.....	5
Battery warning	5
Notes on Installation	5
Product Information	6
1 Introduction 6	
1.1 Features	6
1.2 Package Contents	6
1.3 Product Overview	6-7
2 Getting Started.....	7
2.1 Inserting the Memory Card.....	7
2.2 Installing in Vehicles	7
2.2.1 Mounting the Car Dash Cam to the Windscreen	7
2.2.2 Removing the Car Dash Cam from the Windscreen.....	7
2.2.3 Adjust the position of the Car Dash Cam.....	8
2.2.4 Mounting the Rear view camera to the rear windscreen	8
2.2.5 Connecting the Car Dash Cam to the rear view camera	8
2.2.6 Adjusting the rear view camera	8
2.2.7 Connecting the Car Dash Cam to the rear view camera	9
2.3 Connecting to Power.....	9
2.4 LED Indicator.....	10
2.5 Powering the Device On / Off.....	10
2.5.1 Auto Power On / Off.....	10
2.5.2 Manual Power On / Off and Reset	10
2.5.2.1 Manual Power On	10
2.5.2.2 Power Off.....	10
2.5.2.3 Reset the device	10
2.6 Initial Settings	11
2.6.1 Set the Timezone.....	11
2.6.2 Set the Date / Time.....	11
3 Using the Car Recorder.....	12
3.1 Recording Videos	12
3.1.1 Record videos while driving.....	12

3.1.2	Emergency Recording.....	12
3.1.3	The Recording Screen.....	13
3.1.4	Taking Snapshots.....	14
3.2	Driving Safety	14
3.2.1	Lane Departure Warning System (LDWS)	14-15
3.2.2	Forward Collision Warning System (FCWS)	15-16
3.2.3	Front Car Movement Detection (FMCD).....	16-17
3.2.4	Headlight Warning.....	17
3.2.5	Add speed point	18
3.2.6	Speed Cam Alert.....	18
3.2.7	Speed Limit Alert.....	19
3.2.8	Driver Fatigue Alert.....	19
3.2.9	Parking Mode	20
3.2.10	Collision Detection	21
3.3	Playing Videos and Viewing Pictures.....	22
3.3.1	Playing Videos and Emergency Recordings.....	22
3.3.2	Viewing Pictures.....	22-23
3.3.3	The Playback Screen	23
3.3.4	Deleting Files.....	24
3.3.5	Delete All.....	25
4	Adjusting the Settings	25
4.1	Using the Menu	25
4.2	Menu Items.....	26-27
5	Installing the Software.....	28
6	SuperCar File Viewing Software	28
7	Menu	29-30
8	Specifications	31
	About this Guide.....	32
	Warranty.....	33

Caution

- Ensure you are using your Car Dash Cam within your countries' road laws. Please make sure you are familiar with your local road legislation before use.
- Avoid leaving your Car Dash Cam in direct sunlight for extended periods of time in an unventilated space.
- Please set time and date before you use this device to record.
- The notifications given by the Car Dash Cam are suggestions only, please drive to the actual conditions.
- The results of GPS positioning are only for reference. The Car Dash Cam will lose GPS positioning abilities when signal is blocked (eg driving through tunnels, enclosed car parks).
- GPS positioning accuracy may vary depending on weather and surroundings such as dense cities, tunnels, or forests. GPS satellite signals cannot pass through most solid materials. Tinted windows may also affect the GPS signal.
- The values displayed in this system, such as speed, position, and the distance warning, may be affected by the surrounding environment.
- The system is to be used only for non-commercial use, within the limits permitted by the relevant laws.
- Avoid using the Car Dash Cam in the vicinity of any devices that emit radio interference (eg. Microwave Ovens).
- It is considered normal operation for the Car Dash Cam to get warm during use.

Battery Warning

- Always charge the Car Dash Cam using the provided charger. Improper charging of the Car Dash Cam and may result in failure of the internal battery.
- Never dismantle the Car Dash Cam or expose the internal battery.
- Do not dispose of the Car Dash Cam in fire.
- Dispose of the Car Dash Cam observing local regulations being mindful of the internal battery.
- Do not attempt to replace or expose the internal battery.

Notes on Installation

- It is advised that the Car Dash Cam is installed near the rear view mirror, at the top centre of the windshield for optimal operation.
- Make sure that the lens is within the range of the windscreen wiper to ensure a clear view when it rains.
- Do not touch the lens with your fingers. Finger prints left on the lens will result in unclear videos or photos. If photos or videos are blurred, please clean the lens gently with a microfibre cloth.
- Do not install the device on a tinted window. Doing so may damage the tint film and restrict the Car Dash Cam's GPS signal.
- Make sure that the installation position does not hinder or block the field of view or GPS signal.
- Only use the included charging cable to power the Car Dash Cam.

Product Information

For latest manual and product updates please visit our website at www.kapturecam.com.au or www.kapturecam.co.nz

1. Introduction


Thank you for purchasing a Kapture Car Dash Cam. Please read through these instructions before attempting to install or use this product.

1.1 Features

- Recording Quad HD 1440p footage at 30 frames per second (Front Camera)¹
- Recording Full HD 1080p footage at 30 frames per second (Rear Camera)
- 3.0" LCD screen
- 155° Wide angle lens (Front Camera) / 130° Wide angle lens (Rear Camera)
- Advanced Driver Assistance Systems (ADAS)
- Automatic Emergency recording for collision detection
- Supports MicroSD memory cards Class 6 and above, 16GB or above (up to 32GB)

¹ Front camera can be set to record footage at 1440P @ 30fps when in single channel mode (front camera only). When dual channel mode (front and rear camera) is selected, the maximum resolution for the front camera will be set to 1080P @ 30fps.


1.2 Package Contents



1.3 Product Overview


In Car Dash Cam

1. LED Indicator
2. LCD Colour Screen
3. Menu (☰) / Back Button (⏪)
4. Up (▲) / Add Speed Point Button (📍)
5. Down (▼) / Photo (📷) Button
6. OK (⏹) & Confirm / Emergency Recording (🚗) Button
7. Switch Camera (🔄) Button
8. Speaker
9. Wide Angle Lens
10. Micro SD Card Slot
11. Microphone
12. Power (Off/On) Switch
13. Power (DC-IN) USB Input
14. HDMI Video Port
15. Rear View Camera USB Input
16. Socket for Windscreen Suction Mount



Rear View Camera


1. Wide Angle Lens
2. Rear Camera Swivel Base
3. Micro USB Cable Input
4. Rear Camera Vertical Rotator
5. Rear Camera Horizontal Rotator



2. Getting Started

2.1 Inserting Memory Card

With the screen view towards you, insert memory card with the pins view toward you as illustrated. Push the memory card in. Slide the Power button into ON/LOCK position which will lock the micro SD card in position.



Note:

1. Do not remove or insert the memory card when the device is turned on. This may damage the memory card.
2. Please use a Class 6 or higher rated Micro SD card, 16GB or above (up to 32GB).
3. Please format the Micro SD card before the initial use.

Removing Memory Card

Ensuring the power switch is in the off position (refer to 'power off' image on page 10) simply pull the micro SD card from the slot.


2.2 Installing in Vehicles

2.2.1 Mounting the Car Dash Cam to the Windscreen

1. Push the bracket into bracket slot on top of device, and slide the mount from right to left until a click sound is heard.
2. With the suction-cup lock switch in the down orientation, position the suction-cup on the windshield.¹



3. Hold the base firmly on the windscreen and push the locking switch up to mount the car holder to the windscreen. Make sure the base is securely locked in place.²



Note: For optimum operation it is advised that the KPT-942 is installed near, or behind your vehicles rear view mirror.

2.2.2 Removing the Car Dash Cam from the Winds

1. Release the locking switch as shown in the picture below.




2. Pull the plastic tab on the suction cup to loosen the mount from the windscreen.




2.2.3 Adjust the position of the Car Dash Cam

1. Loosen the knob and adjust the device vertically and/or horizontally.
2. Tighten the knob to make sure the device is securely locked in place.




3. To remove the device, push the release of the left side of the mount and slide off.





2.2.4 Mounting the Rear view camera to the Rear Windscreen

1. Remove the protective white label from the double sided tape exposing one side of the adhesive pad.
2. Press the adhesive pad firmly on the base of the rear view camera.



3. Remove the protective red label from the double sided tape exposing the other side of the adhesive pad.
4. Press the camera base firmly to the desired location on your rear windscreen. Hold on the rear windscreen for 30 seconds to ensure the adhesive pad is securely in place.



2.2.5 Connecting the Car Dash Cam to the Rear view Camera


1. Using the supplied 6M micro USB extension cable, connect one end of the cable to the port marked 2CH on the Car Dash Cam.
2. Run the cable neatly along or under your vehicles' interior trim to the Rear View Camera and connect the other end of the cable to the Rear View Camera's micro USB port.

2.2.6 Adjusting the Rear View Camera

Please use only the included charger to power and charge the built-in battery. It is advised that the Car Dash Cam is installed near the rear view mirror, at the top centre of the windscreen for optimal operation.


Adjusting for recording out of rear windscreen:

1. Rotate the camera mounting shaft 180° away from the camera base.
2. Rotate the camera lens 180° so that it is view the rear view of your vehicle.



Adjusting for recording inside of vehicle:

1. Rotate the camera lens 180° so the camera lens is view the interior view of your vehicle.
2. Rotate the camera mounting shaft 180° so that the camera lens aligns with the camera base.
3. Adjust the view of the camera lens by rotating the camera as shown.




Note:

It is recommended to disconnect the micro USB cable from the rear view camera before adjusting.

2.2.7 Connecting the Car Dash Cam to the Rear View Camera



1. Using the supplied 6M micro USB extension cable, connect one end of the cable to the port marked 2CH on the Car Dash Cam.
2. Run the cable neatly along or under your vehicles' interior trim to the Rear View Camera and connect the other end of the cable to the Rear View Camera's micro USB port.



2.3 Connecting to Power

Note: Please use only the included charger to power and charge the built-in battery. It is advised that the Car Dash Cam is installed near the rear view mirror, at the top centre of the windscreen for optimal operation.

1. Run the cable neatly along or under your vehicles' interior trim to the Car Dash Cam.
2. Insert the USB power cable into the port marked DC-IN.









3. Plug the other end of the USB power cable to the cigarette lighter socket or 12V power source of your vehicle. Once the vehicle engine is started, the device automatically powers up and begins to record.

Note:

1. This product contains functions such as LDWS (3.2.1) FCWS (3.2.2) and FCMD (3.2.3). Please refer to the alignment measures given in these sections during their installation for improved accuracy.
2. The built in battery is designed for short use only to run parking mode when your vehicle is parked and the Car Dash Cam is not receiving power. The battery cannot power the device long term, for everyday use please ensure that the Car Dash Cam is powered by the included Charger.
3. If your vehicle has side curtain airbags please be very careful when running cables along your vehicles windows. Ensure you are not running cables past any of the airbags as this can prevent the airbags from deploying.

Battery Status Indicator

ICON	DESCRIPTION		
	Full battery power.		Low battery.
	2/3 battery power.		Battery charging.
	1/3 battery power.		Connect the car adapter to charge the battery.

Note:

Please take note if the environment temperature reaches 45°C or above, the car adapter will supply power to device, but the Lithium-ion battery will not charge. This is a characteristic of Lithium-ion batteries and is not a malfunction.

2.4 LED Indicator

STATUS EXPLANATION	LED INDICATOR COLOUR
Power off, battery charging	Red
Power off, battery fully charged	LED light off
Power on, battery charging	Red
Power on, battery fully charged	Green
Standby / Standby with screen off	Green
Recording / Recording with screen off	Flashing red

2.5 Powering the Device On / Off

2.5.1 Auto Power On/Off

Once the vehicle engine is started, the device will automatically power up and start recording.

2.5.2 Manual Power On/Off and Reset

2.5.2.1 Manual Power On



Slide the **power switch** making sure that the power switch locks over the memory card slot.

2.5.2.2 Power Off

Slide the **power switch** making sure that the memory slot is open. The device will start the power down sequence. Do not power on the device during the power down sequence, as the recorded data may be corrupted.

2.5.2.3 Reset the Device

If the device does not function normally, try restarting the Car Dash Cam. To restart your Car Dash Cam, slide the **power switch** into the off position and verify the Micro SD Card is in the removable state; wait for 7 seconds and slide the power switch back to the on position to restart the device.



2.6 Initial Settings

Before using the Car Dash Cam, we recommend you enable the **Automatic Record** function and set the correct **Date and Time**.

2.6.1 Set the Timezone









To set the correct date and time, please follow the instructions below:

1. Press  (shown on screen as ) to enter the **Main Menu**.
2. Use the  and  buttons to navigate to the **Timezone** menu.
3. Use the  and  buttons to select the GMT timezone you are located in, and press the **OK** button to confirm.
4. Press  to return to the recording screen.





2.6.2 Set Date and Time

To set the correct date and time, please follow the instructions below:

1. Press  (shown on screen as ) to enter the **Main Menu**.
2. Use the  and  buttons to navigate to the **Date/Time** menu.
3. Use the  and  buttons to adjust the value and then press the **OK** button to set and move to the next field.
4. Press  to save the **Date/Time**, and return to the menu.
5. Press  to return to the recording screen.



Note:



1. If GPS is enabled the Car Dash Cam clock will be synchronised with the satellite clock signal based on the time zone specified in the Set Timezone menu.
2. If satellite positioning is not available, the Car Dash Cam clock will need to be set manually using the **Date/Time** setting.
3. Please be aware that pressing the  (shown on screen as ) button during the recording process will stop the recording and enter the menu.

3. Using the Car Dash Cam

3.1 Recording Videos

3.1.1 Record videos while driving

When the vehicle is started the Car Dash Cam will automatically turn on and start recording. During the Car Dash Cam's start up sequence the buttons and menus will be unresponsive.


Recording will automatically stop when the vehicle is powered off. To manually stop recording press the  (shown on screen as ) button.

Note:

1. Because of how some vehicles are wired, the recording may continue when the engine is switched off. If this happens, please manually turn off the Car Dash Cam or remove the cigarette lighter adapter from the 12V power source when not in use.
2. The recording loop length can be configured to save a video file for every 1 or 3 minutes of recording. For information on how to adjust this setting please refer to **Video Duration** (4.2).
3. The device saves the recording on the inserted Micro SD Card (not included). If the memory card capacity is full, the oldest file in the memory card is overwritten.

3.1.2 Emergency Recording

Emergency Recording saves the current video file and protects it from being overwritten. To start the Emergency Recording, please follow the instructions below:

1. During video recording, press the button marked **OK** (shown on screen as ) to enter emergency recording mode, the "Emergency" message will be shown on the upper left corner of the screen, and the recorded file will be protected.

Note:

1. If the Collision Detection function is enabled and a collision is detected, the device will automatically trigger the emergency recording and protect the current video file. For more information on this feature, please refer to Collision Detection (3.2.10).
2. The emergency recording file is created as a new file, which will be protected to avoid being overwritten by normal loop recording.




3.1.3 The Recording Screen



No.	ICON	ITEM	DESCRIPTION
1		Recording Duration	Indicates the current video duration.
2		Date / Time	Indicates the current recording date and time.
3		Menu Button	During video recording, press the button to enter the OSD menu.
4		Add Speed Point Button	During video recording, press the button to add a speed cam point.
5		PIV (Photo in Video) Button	Press to capture video screen shots from the front camera.
6		Emergency Recording Button	During video recording, press the OK button to enter emergency recording mode. Please refer to Emergency Recording (3.1.3).
7		Switch Camera Button	Press to switch VIV screen.
8		Voice Record Icon	Indicates voice recording sets as off, the sound will not be recording.
9		Resolution Icon	Indicates the video resolution.
10		Satellite Positioning Icon	Indicates the strength of satellite positioning. If the icon shows up on screen, it indicates that the device cannot complete the satellite positioning.
11		Battery Power Icon	Indicates battery or device charging status.
12		VIV (Video in Video)	Indicates rear camera recording screen.

3.1.4 Taking Snapshots

You can also use your Car Dash Cam to take snapshots.

1. Press  (shown on screen as ) in recording mode to take a snapshot.
2. A snapshot is taken when this  icon appears at centre of screen.

Note:

The definition of photos taken by this product when it is recording and the car is moving is subject to the speed of the target object and changes in ambient lighting. The photograph function is better used for taking still pictures after an accident when all vehicles involved have stopped.



3.2 Driving Safety







Note:

1. **Driving Safety** (ADAS - Advanced Driver Assistance Systems) functions are limited to triggering no more than two alerts at the one time. If a voice alert message has been triggered, any other alarms will be halted until the first alert has finished.
2. The speed cam prompt is disabled if this product is not connected to an external power source.



3.2.1 Lane Departure Warning System (LDWS)

Once your car's location is determined by GPS and the **LDWS** function is enabled, the Car Dash Cam produces voice and on screen alerts when your car leaves or changes lanes at speeds over 50 km/h.

To set the **LDWS**, please follow the instructions below:

1. Press  on screen as  to enter the **Main Menu**.
2. Use the  and  buttons to navigate to **Lane Departure Warning System** and press the **OK** button to enter the menu.
3. Use the  and  buttons to change the setting ON or OFF and press **OK** to confirm.



- Press  to exit the menu and return to the recording screen.
- After enabling **LDWS**, the screen will display alignment guidelines  please adjust the position of the Car Dash Cam so that the horizontal guideline and the horizon line overlap, and the diagonal lines are aligned with the lane markings on screen. Make sure that the guide lines are not obscured by any part of your vehicle (e.g. hood) during installation, as this may affect the accuracy of **LDWS**.
- Once your car's location is determined by GPS, this product produces voice and screen message alerts when you change lanes at speeds over 50 km/h.










Note:

- LDWS** is only active when satellite positioning is available. Make sure GPS settings on your Car Dash Cam is activated
- The Driving Safety functions such as LDWS, FCWS, FCMD, Headlight Warning, Speed Cam Alert, Speed Limit Alert, and Driver Fatigue Alert will be disabled if the product isn't powered by the vehicles' 12V power supply.
- The **LDWS** function may give false alarms in poor conditions, including rainy or cloudy weather, at night, or in poor lighting environments and can be triggered by external factors while not changing lanes. Drivers are advised to exercise discretion based on actual road conditions.


3.2.2 Forward Collision Warning System (FCWS)

Once your car's location is determined by GPS and the **FCWS** function is enabled, this product produces voice and screen message alerts when you drive at speeds over 60 km/h and are less than 20m away from the car in front of you.

To set the **FCWS**, please follow the instructions below:

- Press  (shown on screen as ) to enter the **Main Menu**.
- Use the  and  buttons to navigate to **Forward Collision Warning System** and press the **OK** button to enter the menu.
- Use the  and  buttons to change the setting ON or OFF and press **OK** to confirm.
- Press  to exit the menu and return to the recording screen.



- After enabling **FCWS**, the screen will display alignment guidelines  please adjust the position of the Car Dash Cam so that the horizontal guideline and the horizon line overlap and the diagonal lines are aligned with the lane markings on screen. Make sure that the guide lines are not obscured by any part of your vehicle (e.g. hood) during installation, as this may affect the accuracy of **FCWS** functionality.
- Once your car's location is determined by GPS, this product produces voice and screen message alerts when you change lanes at speeds over 50 km/h.











Note:

- FCWS** is only active when satellite positioning is available. Make sure GPS settings on your Car Dash Cam is activated.
- The **Driving Safety** functions such as **LDWS**, **FCWS**, **Headlight Warning**, **Speed Cam Alert** and **Driver Fatigue Alert** will be disabled if the product isn't connected to the external power supply.
- The accuracy of the **FCWS** function is affected by poor visibility conditions, including rainy or cloudy weather, at night, or in poor lighting environments. Drivers are advised to exercise discretion based on actual road conditions.

3.2.3 Front Car Movement Detection (FCMD)

Once your vehicle's location is determined by GPS and the FCMD function is enabled, the Car Dash Cam will detect the movement of the traffic in front of you. When your car remains motionless for 20 seconds it produces voice and on screen alerts when the car in front of you moves forward.

To set the **FCMD**, do the following:

- Press  (shown on screen as ) to enter **Main Menu**.
- Use  and  buttons to navigate to **Front Car Movement Detection** and press **OK** to enter the menu.
- Use  and  buttons to change the setting ON or OFF and press **OK** to confirm.
- Press  to exit the menu and return to the recording screen.
- After enabling **FCMD**, the screen will display align icon  please adjust the Car Dash Cam so that the horizontal guideline and the horizon line overlap and the diagonal lines are aligned with the lane markings on screen. Make sure that the guide lines are not obscured by any part of your vehicle (e.g. hood) during installation, as this may affect the accuracy of **FCMD** functionality.



6. Once your car's location is determined by GPS, when your vehicle is motionless for 20 seconds the Car Dash Cam produces voice and on screen alerts when the movement of the traffic in front of you moves forward.

Note:








1. **FCMD** is only active when satellite positioning is available. Make sure GPS setting on your Car Dash Cam is activated.
2. The **Driving Safety** functions such as **LDWS**, **FCWS**, **Headlight Warning**, **Speed Cam Alert** and **Driver Fatigue Alert** will be disabled if the product isn't connected to the external power supply.
3. The **FCMD** function may give false alarms in poor visibility conditions, including rainy or cloudy weather, at night, or in poor lighting environments. Drivers are advised to exercise discretion based on actual road conditions.
4. **FCMD** will automatically recalibrate 30 seconds after the initial alert if the **FCMD** function has been activated.



3.2.4 Headlight Warning

The **Headlight Warning** function produces voice and screen message alerts when the Car Dash Cam detects poor lighting conditions. To set the headlight warning, please follow the instructions below:

To set the headlight warning, please follow the instructions below:

1. Press  (shown on screen as ) to enter **Main Menu**.
2. Use  and  buttons to navigate to **Headlight Warning** and press **OK** to enter the menu.
3. Use  and  buttons to change the setting ON or OFF and press **OK** to confirm.
4. Press  to exit the menu and return to the recording screen.
5. The Car Dash Cam will now produce voice and on screen alerts when it detects poor lighting conditions.





Note:

The **Driving Safety** functions such as **LDWS**, **FCWS**, **Headlight Warning**, **Speed Cam Alert** and **Driver Fatigue Alert** will be disabled if the product isn't connected to the external power supply.

3.2.5 Add speed point

You can manually add speed cam positions in this Car Dash Cam.








1. Press  (shown on screen as ) to add new **Speed Camera Position** during recording.
2. Up to 200 speed camera points can be saved.
3. This product has a capacity of 200 speed cam positions. In case you are trying to add more than that the system prompts with message "**Speed Position is full**".

Note:

1. You may delete custom speed cam positions by selecting the **Delete speed** point option from the **File / Position** menu. Please note that all of your existing speed cam positions are deleted once the **Delete speed point** option is selected. Make sure you are ready to recreate all of your custom speed cam positions before activating this option.
2. It is recommended that you add the new Speed Camera position on the approach to the speed camera, so the Car Dash Cam will alert you ahead of time.

3.2.6 Speed Cam Alert



Once your car's location is determined by GPS and is approaching a manually saved speed camera location the Car Dash Cam produces voice and on screen alerts. To enable or disable **Speed Cam Alert** please follow the instructions below:

1. Press  (shown on screen as ) to enter **Main Menu**.
2. Use  and  buttons to navigate to **Speed Cam Alert** and press **OK** to enter the menu.
3. Use  and  buttons to change the setting ON or OFF and press **OK** to confirm.
4. Press  to exit the menu and return to the recording screen.
5. Once your car's location is determined by GPS and approaches a manually saved speed camera location the Car Dash Cam produces voice and screen message alerts. The on screen alert will display red to remind you to slow down if you are driving faster than the speed limit.










Note:


1. **Speed Cam Alert** is only active when satellite positioning is available. Make sure GPS settings on your Car Dash Cam is activated.
2. The Driving Safety functions such as LDWS, FCWS, Headlight Warning, Speed Cam Alert, and Driver Fatigue Alert will be disabled if the product isn't connected to your vehicles' 12V power supply.
2. The speed cam alert will only give alerts for speed camera points that have been set by the user. To set a speed camera point press

 (shown on screen as ) as your vehicle approaches a speed camera.

3.2.7 Speed Limit Alert

If the Speed Limit Alert function is enabled, the Car Dash Cam will give you audio alerts once your car's location is determined by GPS and the vehicles speed exceeds the set limit. To set the Speed Limit Alert, follow the instructions below:

1. Press  (shown on screen as ) to enter **Main Menu**.
2. Use  and  buttons to navigate to **Speed Limit Alert** and press **OK** to enter the menu.
3. Use  and  buttons to setup a **Speed Limit Alert** to trigger the Car Dash Cam's alarm (Off / 50 km/h ~ 200 km/h) and then press **OK** to confirm.
4. Press  to exit the menu and return to the recording screen.
5. If a **Speed Limit Alert** is set, the Car Dash Cam will alert the driver with a series of beeps once your car's location is determined by GPS and its speed exceeds the set limit.










Note:

1. **Speed Limit Alert** is only active when satellite positioning is available. Make sure GPS settings on your Car Dash Cam is activated.
2. The **Driving Safety** functions such as LDWS, FCWS, Headlight Warning, Speed Cam Alert and Driver Fatigue Alert will be disabled if the product isn't connected to the external power supply.

3.2.8 Driver Fatigue Alert

If the **Driver Fatigue Alert** function is enabled, the Car Dash Cam produces voice and on screen alerts an hour after recording has started and will repeat the alerts every half an hour afterwards. To set the driver fatigue alert, follow the instructions below:

1. Press  (shown on screen as ) to enter **Main Menu**.
2. Use  and  buttons to navigate to **Driver Fatigue Alert** and press **OK** to enter the menu.
3. Use  and  buttons to change the setting ON or OFF then press **OK** to confirm.
4. Press  to exit the menu and return to the recording screen.
5. If a **Driver Fatigue Alert** is set, the Car Dash Cam will give a voice alert once your Car Dash Cam has been recording for one hour, and every half an hour afterwards.



Note:

- The **Driving Safety** functions such as LDWS, FCWS, Headlight Warning, Speed Cam Alert and Driver Fatigue Alert will be disabled if the product isn't connected to the external power supply.





The following driver safety functions are for reference only. Drivers are advised to exercise discretion based on actual road conditions.

3.2.9 Parking Mode

Parking Mode can be set to trigger recording when your vehicle is parked and powered off and an impact is detected via the G-Sensor or when movement is captured in front of the camera lens via **Motion Detection**. To set

Parking Mode, please follow the steps below:



1. Press  (shown on screen as ) to enter **Main Menu**.
2. Use  and  buttons to navigate to **Parking Mode** and press **OK** to enter the menu.
3. In this menu you can select the **Motion** and **Collision Detection** or **Vibration Detection** to activate parking mode. This will trigger a video recording if motion is detected in front of the camera or if your vehicle experiences an impact while your vehicle is parked and powered off.
4. Press **OK** to exit the menu and return to the recording screen.
5. Once the accessories power on your vehicle is turned off, the message "Enter Parking Mode after 10 seconds" will appear. The Car Dash Cam will automatically enter Parking Mode in 10 seconds, which enables the auto recording function if an impact is detected or any object moving in front of the Car Dash Cam is captured by the camera.








Note:

1. The emergency recording file is created as a new file, which will be protected to avoid being overwritten by normal loop recording. The alert message of "Emergency files are full" will appear on the screen when the emergency recording files are full, and the oldest emergency file will be automatically deleted when a new emergency recording file is created.
2. Each time **Parking Mode** is activated by G-Sensor or **Motion Detection**, the Car Dash Cam will record for 3 minutes. After this time, the Car Dash Cam will return to normal loop recording.
3. **Parking Mode** event recordings can be found in the "Parking Mode" folder of your micro SD card.
4. **Collision Detection** and **Motion Detection** recordings can be found in the "Events" folder of your micro SD card.
5. **Parking Mode** will still be active after the screen turns off.

3.2.10 Collision Detection (G Sensor)

The sensitivity of the Collision Detection function is set to medium by default. The Car Dash Cam will start an emergency recording once it detects any vibrations caused by a collision. To change the settings of Collision Detection:



1. Press  (shown on screen as ) to enter **Main Menu**.
2. Use the  and  buttons to navigate to **Collision Detection** and press **OK** to enter the menu.
3. Use the  and  buttons to change the sensitivity of the Car Dash Cam's collision detection (Off / Low Sensitivity / Normal Sensitivity / High Sensitivity).
4. Press  to exit the menu and return to the recording screen.















Note:

1. The emergency recording file is created as a new file, which will be protected to avoid being overwritten by normal loop recording. The alert message of "Emergency files are full" will appear on the screen when the emergency recording files are full, and the oldest emergency file will be automatically deleted when a new emergency recording file is created.
2. Each time **Parking Mode** is activated by **G-Sensor** or **Motion Detection**, the Car Dash Cam will record for 3 minutes. After this time, the Car Dash Cam will return to normal loop recording.
3. **Parking Mode** event recordings can be found in the "Parking Mode" folder of your micro SD card.
4. **Collision Detection** and **Motion Detection** recordings can be found in the "Events" folder of your micro SD card.
5. **Parking Mode** will still be active after the screen turns off.

3.3 Playing Videos and Viewing Pictures

3.3.1 Playing Videos and Emergency Recordings












Playback video files as follows:

1. Press  (shown on screen as ) to enter **Main Menu**.
2. Use  and  buttons to navigate to **File Playback** and press **OK** to enter the menu.
3. Use the  and  buttons to navigate to **Video**, **Parking Mode** or **Emergency**.
4. Use the  and  buttons to browse the selected files and press **OK** to enter playback mode.
5. If the file displays  icon, it indicates the file chosen is a dual channel recording (front and rear simultaneously). In playback mode, you can use the  button to switch between the front and rear recording.
6. While playing a video, press  to stop playback and return to the file browser.
7. Press  to return to the **File Playback** menu.
8. Press  to return to the **Main menu**.
9. Press  to exit the menu and return to the recording screen.







3.3.2 Viewing Pictures

View pictures as follows:
























1. Press  (shown on screen as ) to enter **Main Menu**.
2. Use the  and  buttons to navigate to **File Playback** and press **OK** to enter the menu.
3. Use the  and  buttons to navigate to **Picture**.
4. Use the  and  buttons to browse the selected files and press **OK** to enter picture playback mode.
5. Press  to view the selected **Picture**.
6. While in picture playback mode, use the  and  buttons to navigate between saved pictures.



7. While viewing a photo, press  to stop playback and return to the file browser.
8. Press  to return to the **File Playback** menu.
9. Press  to return to the **Main menu**.
10. Press  to exit the menu and return to the recording screen.

3.3.3 The Playback Screen



No.	ICON	ITEM	DESCRIPTION
1		File Number / Total File	Indicates the total number of files.
2		Fast Forward / Fast Rewind Icon	Indicates video fast-forward and rewind status.
3		File Name	Indicates the file name of the video / picture.
4		Return	Press the  button to return to preview screen of video or picture. Press the  button repetitively to return to recording screen.
5		Fast Rewind / Previous File Button	When playing videos, press the  button will reverse the playback. Press  button to view previous file.
6		Fast forward / Next File	When playing videos, press the  button to fast forward playing video. Press  button to view next file.
7		Playback/ Pause	Press the  button to play or pause the video.
8		Lens Switch Button	In playback mode, press  button to switch files with dual lens recording file.
9		Battery	Indicates the battery or charging status.
10		Playback Duration / Total Duration	Indicates video playback time and total duration.
11		Date and Time	Indicates the date and time of filming.
12		Previous File	When viewing pictures, press the  button and it will switch over to the previous file.
13		Next File	When viewing pictures, press the  button and it will switch over to the next file.

3.3.4 Deleting Files

To delete file(s), do the following:



1. Press (shown on screen as) to enter **Main Menu**.
2. Use the and buttons to navigate to **File Deletion** and press **OK** to enter the menu.
3. Use the and buttons to navigate between **Video**, **Parking Mode**, **Emergency** or **Picture** and press **OK** to enter the menu.
4. Use the and buttons to navigate to **Delete One** and press **OK** to confirm.

ITEM	DESCRIPTION
Delete One	Delete the current file.
Delete All	Delete all files.

Note:









Deleted files cannot be recovered. Please ensure you have backed up your files before deleting them.

5. Use the and buttons to browse the selected files and press **OK** to delete file.
6. Press **OK** to confirm or press to cancel the file deletion.



3.3.5 Delete All

To delete file(s), do the following:

1. Press  (shown on screen as ) to enter **Main Menu**.
2. Use the  and  buttons to navigate to **File Deletion** and press **OK** to enter the menu.
3. Use the  and  buttons to navigate between **Video**, **Parking Mode**, **Emergency** or **Picture** and press **OK** to enter the menu.
4. Use the  and  buttons to navigate to **Delete One** and **Delete All** and press **OK** to confirm.



ITEM	DESCRIPTION
Delete One	Delete the current file.
Delete All	Delete all files.

Note:








Deleted files cannot be recovered. Please ensure you have backed up your files before deleting them.

5. Press **OK** to confirm or press  to cancel the file deletion.
6. Press  to return to the **Main menu**.
7. Press  to exit the menu and return to the recording screen.

4. Adjusting the Settings

4.1 Using the Menu

You can customise the general settings via the on-screen display (OSD) menus.

1. Press  (shown on screen as ) to enter **Main Menu**.
2. Use the  and  buttons to navigate to **Functions** and press **OK** to enter the respective menu.
3. Use the  and  buttons to select, adjust or change the function and press **OK** to confirm the setting.
4. Press  to exit the menu and return to the recording screen.

4.2 Menu Items

Refer to the below table for details of main menu and function list.

DESCRIPTION	AVAILABLE OPTION
Date/Time: Set the date and time.	
Set Timezone: Set the time zone you are in.	GMT+14:00 ~ GMT-12:00
Time Sync: If GPS is enabled the Car Dash Cam clock will be synchronised with the satellite clock signal based on the time zone specified in the Set Timezone menu.	On / Off
Language Setting: Set the on-screen display menu language.	English, Spanish, Portugese, Russian, Chinese Traditional, Chinese Simplified, German, Italian, French, Japanese, Korean, Turkish, Dutch
LCD Setting: Set the amount of time of inactivity before the Car Dash Cam screen goes into sleep mode. (Recording not affected while screen is in sleep mode)	Off / On / Turn off after 3 min / Turn off after 30 secs.
Satellite Synchronisation: Selects if satellite system (GPS) is enabled or disabled.	Off / On
Format: Format the memory card inserted in the Car Dash Cam. All the files on the card will be erased.	Yes / No
Default Setting: Reset the Car Dash Cam to factory default settings.	Yes / No
Firmware Version: Indicates the current Firmware.	
Video: Play or Delete a video file.	
Picture: View or Delete a picture file.	
Emergency: Play or Delete an emergency record file.	
Add speed point: Manually add speed camera points (up to 200 user defined speed points can be added).	
Delete speed point: Delete all the user defined speed points from the Car Dash Cam.	
Speed Unit: Change the Car Dash Cam setting for displaying speed.	KM/H ~ MPH
LDWS: Once your car's location is determined by GPS and the LDWS function is enabled, this product produces voice and screen message alerts when you drive off of or change lanes at speeds over 50 km/h	On/Off
FCWS: When FCWS is activated after satellite positioning, device will issue a voice and on screen alert when the vehicle speed is above 60 km/h and the distance to the vehicle in front is less than 20m.	On / Off

DESCRIPTION	AVAILABLE OPTION
FCMD: Once your car's location is determined by GPS and the FCMD function is enabled, the Car Dash Cam will detect the movement of the traffic in front of you after your car remains motionless for 20 seconds. It produces voice and on screen alerts when the traffic in front of you moves forward.	On / Off
Headlight Warning: When Headlight Warning is activated, the Car Dash Cam will give on screen and voice alerts reminding that low light conditions are detected.	On / Off
Speed Cam Alert: If the Speed Cam Alert function is enabled, once your car's location is determined by GPS and approaches a recorded speed camera saved location, the Car Dash Cam produces voice and onscreen alerts. (Speed camera data is plotted manually by the user)	On / Off
Speed Limit Alert: If the Speed Limit Alert function is enabled, the Car Dash Cam will give on screen and audio alerts once your car's location is determined by GPS and the cars speed exceeds the set limit.	Off / 50 km/h ~ 200 km/h
Driver Fatigue Alert: If the Driver Fatigue Alert function is enabled, the Car Dash Cam produces voice and on screen alerts one hour after it has started recording and repeats the alerts every half an hour afterwards.	On / Off
Parking Mode: If Parking mode is activated, the device will automatically trigger recording when the device detects any motion in front of the car or vibrations. When the battery is fully charged Parking Mode can record continuously for up to 30 minutes.	Motion & Collision Detection / Vibration Detection / Off
Collision Detection: If Collision Detection is activated, the Car Dash Cam begins emergency recording once it detects any vibrations caused by a collision.	Off / Low Sensitivity / Normal Sensitivity / High Sensitivity
Resolution: Setting of video resolution.	FHD (1080P/30fps) HD30 (720P/30fps) HD60 (720P/60fps)
EV: Set the exposure compensation.	+2.0 ~ -2.0
Automatic Record: Setting for enabling Automatic Record after device power on.	On / Off
Video Duration: Set the length of video loop recording.	3 min. / 5 min.
Voice Record: Setting for activating or muting audio recorded video.	On / Off
Time Stamp: Setting for the date and time stamp on the picture or video recorded.	On / Off
WDR: The WDR function compensates for and optimises dim areas in poor external lighting environments.	On / Off

Note:

The **Driving Safety** functions such as **LDWS**, **FCWS**, **Headlight Warning**, **Speed Cam Alert**, and **Driver Fatigue Alert** will be disabled if the product isn't connected to the external power supply.

5. Installing the Software

You can customise the general settings via the on-screen display (OSD) menus.

1. Place the included **CD ROM** into the CD player of your computer.
2. If the CD does not execute automatically, please use Windows File Manager to execute the Install_CD.exe file in the CD.

The screen (as pictured on the right) will be shown.

3. Click SuperCar to start the installation process and follow instructions on-screen.



Note:

1. If you are using a PC that does not have a CD reader, or if you are using a Mac computer, please visit www.kapturecam.com.au to download the SuperCar Software from the product page.
2. For ease of installation and smooth file playback it is recommended to copy the installation software and playback files to your computer desktop before installation or media file playback.

6. SuperCar File Viewing Software

You can view your (.MOV) video files on any computer video playback device like Windows Media Player or QuickTime. However if you would like to view your video files in conjunction with live Google Maps and vehicle vital statistics like speed, direction or G-Sensor you will need to view the files using the supplied **SuperCar software**. To load files, open the software and browse for the file you wish to view.



Note:

1. To display the route on Google Maps, please make sure the internet is connected before starting the video playback.
2. Video files (MOV / TS) and GPS/G-Sensor files (NMEA) must be stored in the same folder before starting the playback.
3. The **SuperCar software** is only applicable to a Windows operating systems however a Mac version is in development, please check the product page at www.kapturecam.com.au periodically for software updates.

No.	ITEM
1	Video Player
2	Play / Pause
3	Previous
4	Next
5	Stop
6	Map
7	Compass
8	Speed Meter
9	File Path
10	Browser File
11	File List
12	File Name
13	Volume
14	Current Duration / Total Duration
15	Signal Noise Ratio (SNR)
16	G-Sensor

7. Menu

MENU	FILE PLAYBACK	VIDEO	PARKING MODE	EMERGENCY
		PICTURE		
	SATELLITE STATUS	DISPLAY SATELLITE STATUS		
	SATELLITE SYNCHRONISATION	OFF	ON	
	SPEED UNIT	KMH	MPH	
	SPEED CAM ALERT	OFF	ON	
	SPEED POSITION MANAGEMENT	ADD SPEED POINT	DELETE LAST POSITION	DELETE ALL POSITION
	SPEED LIMIT ALERT	OFF	50 KM/H	60 KM/H
		70 KM/H	80KM/H	90KM/H
		100KM/H	110KM/H	120KM/H
		130KM/H	140KM/H	150KM/H
		160KM/H	170KM/H	180KM/H
		190KM/H	200KM/H	
	SET TIMEZONE	GMT+14:00	GMT+13:00	GMT+12:00
		GMT+11:00	GMT+10:00	GMT+09:00
		GMT+08:00	GMT+07:00	GMT+06:00
		GMT+05:00	GMT+04:00	GMT+03:00
		GMT+02:00	GMT+01:00	GMT
		GMT-01:00	GMT-02:00	GMT-03:00
		GMT-04:00	GMT-05:00	GMT-06:00
GMT-05:00		GMT-06:00	GMT-07:00	
GMT-08:00		GMT-09:00	GMT-10:00	
GMT-11:00	GMT-12:00			
DATE/TIME	SET DATE & TIME			
LANGUAGE	ENGLISH	SPANISH	PORTUGUESE	
	RUSSIAN	CHINESE TRADITIONAL	CHINESE SIMPLIFIED	
	GERMAN	ITALIAN	FRENCH	
	JAPANESE	KOREAN	TURKISH	
	DUTCH			
TIME STAMP	OFF	ON		
RESOLUTION	1080P 30FPS	720P 120FPS		

MENU	EV	+2	+1	0
		-1	-2	
	LCD SETTING	ON	TURN OFF AFTER 30 SEC.	TURN OFF AFTER 3MIN.
		OFF		
	VOICE RECORD	ON	OFF	
	VOLUME	SET VOLUME (SLIDER 1 -10)		
	VIDEO DURATION	1 MIN.	3 MIN.	
	PARKING MODE	VIBRATION DETECTION	MOTION AND COLLISION DETECTION	
	COLLISION DETECTION	HIGH SENSITIVITY	NORMAL SENSITIVITY	LOW SENSITIVITY
		OFF		
	WDR	OFF	ON	
	DRIVER FATIGUE ALERT	OFF	ON	
	HEADLIGHT WARNING	OFF	ON	
	LDWS	OFF	ON	
	FCWS	OFF	ON	
	FCMD	OFF	ON	
	FILE DELETION	VIDEO	PARKING MODE	EMERGENCY
		PICTURE		
	ANTI-FLICKER	60Hz	50Hz	
	FORMAT	YES	NO	
DEFAULT	YES	NO		
FIRMWARE	DISPLAY FIRMWARE VERSION			

8. Specifications

FUNCTION LIST	DESCRIPTION
Image sensor	Front Camera: 1/3" CMOS sensor Rear Camera: 1/2.7" CMOS sensor
Effective pixels	Front Camera: 2688 (H) x 1520 (V) Rear Camera: 1920 (H) x 1080 (V)
Storage media	Supports Micro SDHC Class 6, min. 16GB, max. 32GB
LCD display	3.0" LCD colour screen
Lens	Front Camera: Wide Angle Fixed Focus lens F1.8, f=2.94mm Rear Camera: Wide Angle Fixed Focus lens F2.0, f=3.8mm
Focus range	Front Camera: 1.5m~Infinity Rear Camera: 1.5m~Infinity
Satellite System	GPS / GLONASS (Satellite Positioning feature varies depending on the model)
Movie Clip	Front Camera Resolution: 2K HD@30 (1440P 30fps) / FHD@60 (1080P 60fps) / FHD HDR (1080P HDR 30fps) / FHD@30 (1080P 30fps) / HD@120 (720P 120fps) Format: MOV Rear Camera Resolution: FHD@30 (1080P 30fps) Format: MOV
Still image (Snapshot)	Resolution: 2M (1920 x 1080) Format: JPEG
Shutter	Electronic shutter Auto: 1/2 ~ 1/2000 sec.
G-Sensor	3-Axis G-Force sensor
ISO	Auto
White Balance	Auto
Microphone	Yes
Speaker	Yes
Interface	Mini USB
Battery	Built-in 470mAh Li-polymer rechargeable
Operating Temperature	0° ~ 50° C
Operating Humidity	20 ~ 70% RH
Storage Temperature	-20° ~ 80° C
Dimensions	80 x 30.4 x 52.3 mm
Weight	Approx. 82g (without memory card)

About this Guide

The content in this document is for information purpose and is subject to change without prior notice. We made every effort to ensure that this User Guide is accurate and complete. However, no liability is assumed for any errors and omissions that may have occurred. The manufacturer reserves the right to change the technical specifications without prior notice.

Warranty Terms & Conditions

Our goods come with guarantees that cannot be excluded under the Australian & New Zealand Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

This warranty is provided in addition to your rights under the Australian & New Zealand Consumer Law.

Directed Electronics warrants that this product is free from defects in material and workmanship for a period of 12 months from the date of purchase or for the period stated on the packaging. This warranty is only valid where you have used the product in accordance with any recommendations or instructions provided by Directed Electronics.

This warranty excludes defects resulting from alterations of the product, accident, misuse, abuse or neglect.

In order to claim the warranty, you must return the product to the retailer from which it was purchased or if that retailer is part of a National network, a store within that chain, along with satisfactory proof of purchase. The retailer will then return the goods to Directed Electronics. Directed Electronics will repair, replace or refurbish the product at its discretion. The retailer will contact you when the product is ready for collection. All costs involved in claiming this warranty, including the cost of the retailer sending the product to Directed Electronics, will be borne by you.

Directed Electronics Address: 44 Translink Drive, Keilor Park Victoria Australia 3042

Ph: +61 03 8331 4800

Email: service@kapturecam.com.au

YOUR EYEWITNESS ON THE ROAD™